



























Applications



· Radio system backup solution

Industrial automation machinery

· Mechanical and electrical equipment

· Electric scooter charger

Specialty vehicles

Surveillance system

Industrial control system







Features

- Multi-function single unit battery charger or power supply operation modes selectable
- Output voltage and current adjustable via potentiometer
- 3-stage charging curve for charging mode
- -30~+70°C wide operating temperature
- Multiple protections: Short circuit / Over load / Over voltage / Over temperature
- Thermal controlled DC fan for noise reduction.
- · Remote ON-OFF control
- Comply with 62368-1+60335-1/-2-29 dual certification
- · Suitable for lead-acid (Pb) batteries

MW Search: https://www.meanwell.com/serviceGTIN.aspx

· Camping car · Buses · Heavy duty truck ·

GTIN CODE


• Carry handle accessory available (Order NO.:DS-Carry handle, sold separately)

3 years warranty

Description

NPP-450 is a miniaturized dual-purpose charger and power supply. In addition to being used as a threestage charger for lead-acid batteries, it can also be used as a constant voltage output power supply to drive general load. The operating mode can be quickly switched by plugging or unplugging a connector on the front panel. Other features include: ultra-wide voltage output, adjustable voltage via VR on the panel (10.5~21V, 21~42V, 42~80V, 54~100V), adjustable charging current (50~100%), built-in intelligent fan with variable speed based on temperature to reduce noise and extend fan lifetime, -30~+70° C wide operating temperature, suitability for use in different environments, built-in remote ON/OFF control, compliance to IEC/EN/UL62368-1 and household EN60335-1/-2-29 dual safety, multiple built-in protections, and 3-year warranty. The NPP-450 is truly an intelligent, safe, and reliable universal dual-purpose charger and power supply with outstanding cost performance.

Model Encoding





SPECIFICATION for Battery Charger mode (Default)

MODEL		NPP-450-12	NPP-450-24	NPP-450-48	NPP-450-72	
	BOOST CHARGE VOLTAGE(Vboost)(default)	14.4V	28.8V	57.6V	72V	
	FLOAT CHARGE VOLTAGE(Vfloat)(default)	13.8V	27.6V	55.2V	69V	
		10.5 ~ 21V	21 ~ 42V	42 ~ 80V	54 ~ 100V	
	VOLTAGE ADJUSTABLE RANGE	By built-in potentionmeter			1	
	MAX. OUTPUT CURRENT(CC)	25A	13.5A	6.8A	5.5A	
OUTPUT	CURRENT ADJUSTABLE RANGE	12.5 ~ 25A	6.75 ~ 13.5A	3.4 ~ 6.8A	2.75 ~ 5.5A	
	Note.3	By built-in potentionmeter			1-11-1-11-11-11-11-11-11-11-11-11-11-11	
	MAX. POWER	420W	453.6W	456.96W	462W	
	RECOMMENDED BATTERY					
	CAPACITY (AMP HOURS) Note.4	90 ~ 300AH	45 ~ 155AH	24 ~ 80AH	19 ~ 64AH	
	VOLTAGE RANGE Note.5	90 ~ 264VAC 127 ~ 370VDC				
	FREQUENCY RANGE	47 ~ 63Hz				
	POWER FACTOR (Typ.)	PF>0.98/115VAC, PF>0.95/2	30VAC at full load			
INPUT	EFFICIENCY (Typ.) Note.6		93%	93%	93%	
	AC CURRENT (Typ.)	4.5A/115VAC 2.2A/230V	'AC		<u> </u>	
	INRUSH CURRENT (Typ.)	COLD START 50A at 230VAC				
	, ,	Protection type : Constant cu	rrent limiting, charger will shu	ıtdown after 5 sec. re-pow	ver on to recover	
		21.5 ~ 26V	43 ~ 52V	82 ~ 100V	102 ~ 120V	
PROTECTION	OVER VOLTAGE	Protection type : Shut down a			1	
	OVER TEMPERATURE	Shut down O/P voltage, recov	1 0 / 1			
	CHARGING STAGE	3 stage only	and allowing untor tompe	3000 40 1111		
		The TTL signal out, Charger (OK - H(4.5 ~ 5.5\/) : Charger t	failure or protection status	s =1 (0 5 ~ ±0 5\/)	
FUNCTION	CHARGER OK SIGNAL BATTERY FULL SIGNAL	The TTL signal out, Charger of		<u> </u>	5 = (0.0 .0.0)	
	REMOTE CONTROL	Open: Charger stop charging	, ,,	,		
	FAN SPEED CONTROL	Depends on internal tempera	, , , , , , , , , , , , , , , , , , , ,	WOIK		
		-30 ~ +70°C (Refer to "Derati				
	WORKING TEMP.	` `	<u> </u>			
ENVERANMENT.	WORKING HUMIDITY	20 ~ 95% RH non-condensing				
ENVIRONMENT	STORAGE TEMP., HUMIDITY					
	TEMP. COEFFICIENT	±0.05%/°C (0 ~ 50°C)				
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycl				
	SAFETY STANDARDS		•	BS EN/EN60335-1/2-29, U	JL62368-1, EAC TP TC 004 approved	
	WITHSTAND VOLTAGE	I/P-O/P:3KVAC I/P-FG:2K				
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100		% RH	I =	
		Parameter	Standard		Test Level / Note	
		Conducted	,	PR32),BS EN/EN55014-1	Class B	
	EMC EMISSION	Radiated	`	PR32),BS EN/EN55014-1	Class B	
		Harmonic Current	BS EN/EN61000-3-2		Class A	
SAFETY &		Voltage Flicker	BS EN/EN61000-3-3			
EMC		BS EN/EN61000-6-2				
(Note 8)		Parameter	Standard		Test Level / Note	
		ESD	BS EN/EN61000-4-2		Level 3, 8KV air ; Level 2, 4KV contact	
		Radiated	BS EN/EN61000-4-3		Level 2, 3V/m	
	EMC IMMUNITY	EFT / Burst	BS EN/EN61000-4-4		Level 2, 1KV	
		Surge	BS EN/EN61000-4-5		Level 2, 1KV/Line-Line,Level 3, 2KV/Line-Ea	
		Conducted	BS EN/EN61000-4-6		Level 2, 3Vrms	
		Magnetic Field	BS EN/EN61000-4-8		Level 1, 1A/m	
		Voltage Dips and Interruptions	BS EN/EN61000-4-1	1	>95% dip 0.5 periods, 30% dip 25 period >95% interruptions 250 periods	
	MTBF	1056.9K hrs min. Telcordia	a SR-332 (Bellcore); 118	.5K hrs min. MIL-HDBk	(-217F (25°C)	
OTHERS	DIMENSION	205*135*55mm (L*W*H)	. , , , , , ,		· · ·	
	PACKING	1.02Kg; 8pcs/ 10Kg / 1.71CUF	T			
NOTE	All parameters NOT special Float charge voltage(Vfloat) This is MEAN WELL's sugg Derating may be needed ur The efficiency is measured 84V charge voltage(72V mc This protection mechanism The charger is considered a a 600mm*900mm metal pla perform these EMC tests, p	Modification for charger specification may be required for different battery specification. Please contact battery vendor and MEAN WELL for details. All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature. Float charge voltage(Vfloat) adjustable via potentiomerter in battery charger mode. This is MEAN WELL's suggested range. Please consult your battery manufacturer for their suggestions about maximum charging current limitation. Derating may be needed under low input voltages. Please check the derating curve for more details. The efficiency is measured at 16.8V charge voltage(12V model), 33.6V charge voltage(24V model), 67.2V charge voltage(48V model), 84V charge voltage(72V model). This protection mechanism is specified for the case the short circuit occurs after the charger is turned on. The charger is considered a component which will be installed into a final equipment. All the EMC tests are been executed by mounting the unit on a 600mm*900mm metal plate with 1mm of thickness. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as available on http://www.meanwell.com) The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500ft).				


Product Liability Disclaimer: For detailed information, please refer to https://www.meanwell.com/serviceDisclaimer.aspx



SPECIFICATION for Power Supply mode (Selectable via pin3 & 4 jumper of 14pins connector on panel)

MODEL		NPP-450-12	NPP-450-24	NPP-450-48	NPP-450-72	
	DC VOLTAGE	14.4V	28.8V	57.6V	72V	
	VOLTAGE AD MOTAE: = 5.445=	10.5 ~ 21V	21 ~ 42V	42 ~ 80V	54 ~ 100V	
	VOLTAGE ADJUSTABLE RANGE	By built-in potentionmeter			<u> </u>	
	CURRENT ADJUSTABLE RANGE	· ·	6.75 ~ 13.5A	3.4 ~ 6.8A	2.75 ~ 5.5A	
	RATED CURRENT	25A	13.5A	6.8A	5.5A	
OUTPUT	RATED POWER	420W	453.6W	457W	462W	
JUIPUI			480mVp-p	600mVp-p		
	VOLTAGE TOLERANCE	±1.0%	±1.0%	±1.0%	±1.0%	
	LINE REGULATION	±0.5%	±0.5%	±0.5%	±0.5%	
	LOAD REGULATION	±1.0%	±1.0%	±0.5%	±0.5%	
		⊥0.5%	±0.3%			
	SETUP, RISE TIME					
	HOLD UP TIME (Typ.)	16ms/230VAC at 75% load 10				
		90 ~ 264VAC 127 ~ 370VE	0C			
	FREQUENCY RANGE	47 ~ 63Hz				
NPUT	POWER FACTOR (Typ.)	PF>0.98/115VAC, PF>0.95/230		1		
	EFFICIENCY (Typ.)	92%	93%	93%	93%	
	AC CURRENT (Typ.)	4.5A/115VAC 2.2A/230VA	<u>C</u>			
	INRUSH CURRENT (Typ.)	COLD START 50A at 230VAC				
	OVERLOAD	105 ~ 115% rated output power				
	O V LINLOAD	Protection type : Constant curre	nt limiting, unit will shutdown afte	5 sec, re-power on to	recover	
	SHORT CURRENT	Protection type : Constant curre	nt limiting, unit will shutdown afte	5 sec, re-power on to	recover	
PROTECTION	AVER VALE: 2-		43 ~ 52V	82 ~ 100V	102 ~ 120V	
	OVER VOLTAGE	Protection type: Shut down and	d latch off o/p voltage, re-power	on to recover	'	
	OVER TEMPERATURE	Shut down O/P voltage, recove				
	REMOTE CONTROL		Power ON			
UNCTION	DC OK		(4.5 ~ 5.5V); Power supply failu	re or protection = 1 (-() 5 ~ +0 5V)	
	FAN SPEED CONTROL	Depends on internal temperatu		o or protoction E(3.0 (0.01)	
	WORKING TEMP.	-30 ~ +70°C (Refer to "Derating				
			Tourve)			
ENVIDONMENT	WORKING HUMIDITY	20 ~ 95% RH non-condensing				
ENVIRONMENT	STORAGE TEMP., HUMIDITY					
	TEMP. COEFFICIENT	±0.05%/°C (0~50°C)				
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycle,				
	SAFETY STANDARDS		· · · · · · · · · · · · · · · · · · ·	EN/EN60335-1/2-29, L	JL62368-1, EAC TP TC 004 approved	
	WITHSTAND VOLTAGE	I/P-O/P:3KVAC I/P-FG:2KVA				
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100M	Ohms / 500VDC / 25°C / 70% RF			
		Parameter	Standard		Test Level / Note	
	EMC EMISSION	Conducted	BS EN/EN55032 (CISPR3	2),BS EN/EN55014-1	Class B	
		Radiated	BS EN/EN55032 (CISPR3	2),BS EN/EN55014-1	Class B	
		Harmonic Current	BS EN/EN61000-3-2		Class A	
SAFETY 0		Voltage Flicker	BS EN/EN61000-3-3			
SAFETY & EMC		BS EN/EN61000-6-2				
Note 4)		Parameter	Standard		Test Level / Note	
		ESD	BS EN/EN61000-4-2		Level 3, 8KV air ; Level 2, 4KV contact	
		Radiated	BS EN/EN61000-4-3		Level 2, 3V/m	
		EFT / Burst	BS EN/EN61000-4-4		Level 2, 1KV	
	EMC IMMUNITY	Surge	BS EN/EN61000-4-5		Level 2, 1KV/Line-Line,Level 3, 2KV/Line-Ea	
		Conducted	BS EN/EN61000-4-6		Level 2, 3Vrms	
			BS EN/EN61000-4-8		·	
		Magnetic Field	D3 EIN/EIN01000-4-0		Level 1, 1A/m	
		Voltage Dips and Interruptions	BS EN/EN61000-4-11		>95% dip 0.5 periods, 30% dip 25 period >95% interruptions 250 periods	
	MTBF	1056.9K hrs min. Telcordia SR-332 (Bellcore); 118.5K hrs min. MIL-HDBK-217F (25°C)				
OTHERS	DIMENSION	205*135*55mm (L*W*H)				
	PACKING	1.02Kg; 8pcs/10Kg / 1.71CUFT				
NOTE	All parameters NOT special Derating may be needed ur The PSU is considered a coa a 600mm*900mm metal plate perform these EMC tests, p The ambient temperature default.	y mentioned are measured at 23 der low input voltages. Please component which will be installed te with 1mm of thickness. The fill lease refer to "EMI testing of corerating of 3.5°C/1000m with fanks	80VAC input, rated load and 25° check the derating curve for more into a final equipment. All the EM all equipment must be re-confirm ponent power supplies." (as averaged in the confirm ponent power supplies."	C of ambient temperal details. MC tests are been exempled that it still meets ailable on http://www.rth fan models for open	ecuted by mounting the unit on EMC directives. For guidance on how to meanwell.com) erating altitude higher than 2000m(6500ft)	







■ Function Manual


1. Battery Charger or Power Supply Operation modes selectable via pin3 and pin4 jumper

Between pin3 and pin4	Operation modes	
Jumper connected	Power supply mode	
Jumper removed	Battery charger mode (Default)	



2. Charging Curve (Charging Mode)


© 3 stage charging curve



State	NPP-450-12	NPP-450-24	NPP-450-48	NPP-450-72
Constant Current	25A	13.5A	6.8A	5.5A
Vboost	14.4V	28.8V	57.6V	72V
Vfloat	13.8V	27.6V	55.2V	69V

O Suitable for lead-acid batteries (flooded, Gel and AGM)





※ V₀ x I₀ must be less than or equal to the rated power. Please refer to derating curve (page 4).

3. Charger OK / DC OK Signal

Charger OK / DC OK signal is a TTL level signal.

The maximum sourcing current is 10mA.

Charger OK / DC OK signal	Charger status
"High": 4.5 ~ 5.5V	Work normally
"Low" : -0.5 ~ 0.5V	Failure or protection function activated



4.Remote ON-OFF Control


The NPP-450 can be turned ON/OFF by using the "Remote Control" function.

Between pin7 remote ON-OFF and pin8 +12Vaux	Charger status
Short (Pin 7 = 10.8 ~ 13.2V)	ON (Default)
Open (Pin 7 = -0.5 ~ 0.5V)	OFF





■ Mechanical Specification



$\frak{\%}$ Connector Pin No. Assignment : HRS DF11-14DP-2DS or equivalent

Pin No.	Assignment	Mating Housing	Terminal
1,2,11~14	NC		
3,4	Battery Charger or		
5,4	Power Supply mode selectable		
5	Battery Full	HRS DF11-14DS	HRS DF11-**SC
6	Charger OK (Charger mode) or	or equivalent	or equivalent
	DC OK (Power supply mode)		
7	Remote ON-OFF		
8	+12V-AUX		
9,10	GND-AUX		

※ LED Status Table

Charger (Default)			
LED Indicator	Status		
Green	Float stage (stage 3) or full charged		
Red	Charging (stage 1 or stage 2)		
O No Light	Abnormal		
Power supply mode			
LED Indicator	Status		
Green	Normal working		
O No Light	Abnormal		



 $\fint M$ Control Pin No. Assignment : HRS DF11-14DP-2DS or equivalent

2	1
14	13

Mating Housing	HRS DF11-14DS or equivalent
Terminal	HRS DF11-**SC or equivalent

Pin No.	Function	Description
1,2,11~14	NC	
3,4	Battery charger / Power supply	Open: Battery charger, Color of LED loading indicator: Reference to battery charger. Short: Power supply, Color of LED loading indicator :Green.
5	Battery Full	Battery Full Signal, referenced to GND-AUX(Pin 9 & 10). The Signal is a TTL level signal. The maximum sourcing current is 10mA and only for output.(Note.2) Low (-0.5 ~ 0.5V): When the battery is charging. High (4.5 ~ 5.5V): When the battery is full.
6	Charger OK / DC OK	Charger OK / DC OK Signal, referenced to GND-AUX(Pin 9 & 10). The Signal is a TTL level signal. The maximum sourcing current is 10mA and only for output.(Note.2) Low (-0.5 ~ 0.5V): When the charger fails or the protect function is activating. High (4.5 ~ 5.5V): When the charger is working properly.
7	Remote ON-OFF	Remote charger ON/OFF Function. The charger can turn the output ON/OFF by dry contact between Remote ON-OFF and +12V-AUX.(Note.2) Short (10.8 ~ 13.2V): Charger ON; Open(-0.5 ~ 0.5V): Charger OFF; The maximum input voltage is 13.2V.
8	+12V-AUX	It is controlled by the Remote ON-OFF control.
9,10	GND-AUX	The signal return is isolated from the output terminal. (+V & -V)

Note1: Non-isolated signal, referenced to [GND(signal)].

Note2: Isolated signal, referenced to GND-AUX


■ Accessory List

Pin 3 and Pin 4 mating pin	Quantity
1FF1HMJ20-020-95BS or equivalent	1




MW's Order No.	Item				
DS-Carry Handle	1	Handle		1	
	2	Foot pad		4	
	3	Screw		2	





2 Foot pad



■ INSTALLATION MANUAL

Please refer to : http://www.meanwell.com/manual.html